

# SAH3-PLC Touch Screen Control System

## Non-woven bag system

### Version Ver2.0

## User Manual

瑞安市辉煌工控设备厂

地址：瑞安市经济开发区

电话：0577-65602858 传真：0577-65006599

网址：[WWW.HHGK.CN](http://WWW.HHGK.CN) E-mail: [hhgk@hhgk.cn](mailto:hhgk@hhgk.cn)

## 一、 Introduction

SAH3-PLC touch screen control system is a factory specially developed for high-speed high-precision fixed-length control of NC product. By high-speed dedicated motion control PLC touch screen, as well as Taiwan and step (servo) motor component. Intuitive operation is simple, widely used in various types of high-speed cross-cutting machine, computer bag machine, woven bag machine and printing, packaging, food, light industry and other industries need to fixed-length control the machine.


## 二、 Control panel



### ➤ Boot screen



- Press the button to enter the Chinese menu, press the button to enter the English menu, English

### ➤ Main Screen





Parameters	Description	MIN	MAX	Initial	Units
Main screen parameter					
Wheel condition	Wheel current state (normal⇔ERR)				pilot lamp
Left limit	Limit the left wheel position (X1 port)				pilot lamp
Right limit	Roller right extreme position (X2 port)				pilot lamp
Number	The number of the current work	0	9999	0	
Lots	The current number of batches of work	0	9999	0	
CLR	Press the number of the Qing, the number of zero, the number of the Qing approved				pilot lamp
Feeding	The length of the current crop	5.0	999.9	25	mm
Rotation	The current angle of rotation	1	360	90	Deg
Heat	Sealing of the working hours	0	9.99	0.50	S
Cover	To return to the boot screen				KEY
SET	Enter the parameter setting screen				KEY
Manual	Manual work to enter the screen				KEY
MODE	Semi⇔AUTO Select the machine works				KEY
Manual Work Screen					
Feeding step	Feeding step, the light				pilot lamp
RUN	Run the switch to open when the light (X0 port)				pilot lamp
Single Switch	Point second switch open, the light (X4 port)				pilot lamp
Auto Switch	Automatic switch to open when the light (X3 port)				pilot lamp
Left limit	Left limit in place, the light (X1 port)				pilot lamp
Right limit	Limit the right place, the light (X2 port)				pilot lamp
Speaker	Is pressed, the speaker output (Y6 port)				KEY
Feeding	Pressed when the feeding step to send a feed				KEY
Rotation	When pressed, spin rotation step once				KEY
Folder Material	Is pressed, the clip materials solenoid valve output (Y2 port)				KEY
Cutter	Is pressed, the cutter solenoid valve output				KEY


	(Y3 port)				
Binder	When pressed, the pressure is expected solenoid valve output (Y7 port)		KEY		
Interpolation	When pressed, which push the solenoid valve output (Y4 port)		KEY		
Heat	Is pressed, the sealing solenoid valve outputs (Y0 port)		KEY		
Left	Is pressed, the wheel stepping to the left to go		KEY		
Right	Is pressed, the wheel to the right step to go		KEY		
Back	Return to the main screen		KEY		
Parameter is set to screen first floor					
The whole number of	The number of single-batch	6	9999	100	张
Cutter Delay	Delay wheel cutter and working hours	0	9.99	0.05	S
Cutter Time	Cutter's working hours	0	9.99	0.20	S
Rotational latency	Delayed rotation step of working hours	0	9.99	0.10	S
Switch Delay	Running Time delay switch	0	9.99	0.05	S
Discharging time	The waiting time for discharge	0	9.99	0.30	S
Password	The lower screen to enter the password	0	9999	0008	
Back	Return to the main screen				
Next	Access to the lower screen (when the password is correct)				
Parameter is set to the second level screen					
Roller Length	Restrictions on the length of roller	100	2000	1000	mm
Roller Speed	Roller of working speed	0	99	15	%
Roller Diameter	The diameter of the feed roller	10.00	99.99	32.50	mm
Feeding speed	Feeding rate of step	0	9	1	d
Default	Initialize all the parameters	KEY			
Password	The lower screen to enter the password	0000	9999	2858	
The third layer parameter setting screen					
Change Password	Change Password	0000	9999	2858	
Limited number of batches	Limited number of batches	0000	9999	0	
Back	Return to the main screen				

Note: To enable the approved limit the number of functions, according to the following methods to set,

λ into the second layer of screen, enter the factory password 2858










λ into the third layer of the screen, set up to limit the number of grant  
λ change the factory password, remember password for your own good  
λ To Jilao modified password, if the password is forgotten, only to return for board factory, and remember

### 三、 Installation dimensions



- feed, wheel pulse of 800-step (S1=OFF, S2=ON, S3=ON, S4=OFF),  
Current 5A (I1=OFF, I2=ON),
- Rotary pulse of 1 / 8 sub (SW1=ON, SW2=ON, SW3=OFF),  
Current 0.84A (SW4=OFF, SW5=OFF, SW6=ON)

### 四、 Wiring diagram



弱点地

弱点地

限位 限位 踏运行 动/手动 次

滚轮步进方向

机架地

步进电机

步进电机

步进电机

步进电机

220V

220V

6